

# CheckPoints™ Plugin for the Android Tactical Assault Kit (ATAK)

Quick Reference Guide



# CheckPoints™ Overview



**CheckPoints™** provides persistent video surveillance at the tactical edge. Networked to allow for local Wi-Fi connections or Wi-Fi disabled to provide video through a closed network or encrypted tactical radio connection.

**CheckPoints™** will give users a “live” view of their position from a fixed location.

**CheckPoints™** allows users to stream up to (2) video feeds through Mobile, Tactical & Command Post systems.

**CheckPoints™** is a low-voltage capability designed for extended operations. The system provides automatic network routing for rapid deployment and ease of use. There is no configuration required and the tool has successfully integrated with APASS & KILSWITCH




# Before We Begin...



This document assumes the following:

1. ATAK Must be installed on the End User Device before installing the CheckPoints™ Plugin.
2. The Reader has followed the steps found in the CheckPoints™ Start Guide
3. The Reader has the system set up and the EUD is receiving an IP Address from the CheckPoints™ System.



This icon indicates the tablet/EUD detects a network connection

This icon indicates the tablet/EUD is receiving an IP address from the CheckPoints™ System

# CheckPoints™ Plugin for ATAK Table of Contents





Install CheckPoints™ Plugin for ATAK .....	1
Load CheckPoints™ Plugin for ATAK .....	2
Launch CheckPoints™ Plugin .....	5
Initial Camera Setup .....	6
User Interface .....	7
Motion Detection .....	8
Camera Status Matrix .....	9
Files Overview .....	10
Files – Recordings .....	11
Files – Snapshots .....	13
Place Camera .....	15
Radial Menu .....	17
Dual Camera / FOV Example .....	18
Preferences Overview .....	19
Access Preferences .....	20
Stream Settings .....	21

# CheckPoints™ Plugin for ATAK Table of Contents cont.




UDP Group and Port .....	22
Camera Motion Alert Settings .....	23
Audio Alert Sound File.....	24
Snap Shot File Type .....	25
JPG Compression .....	26
About CheckPoints™ .....	27
Board Configuration .....	28
Configuration Overview .....	29
Connect to Board .....	30
CheckPoints™ Configurations .....	31
Camera Configuration .....	32
Motion Alertt .....	33
SA Network Settings .....	34
Network IP Address .....	35
TCP Addresses .....	36
Factory Defaults .....	38

# Install CheckPoints™ Plugin for ATAK






1. **Tap** the CheckPoints™ Plugin APK file to begin installation.
2. Review the Permissions Statement then **tap Install**.
3. **Tap DONE** once the installation is complete.

**Note:** You may have to adjust the security settings on your device to install this application.




# Load CheckPoints™ Plugin for ATAK




1. **Launch** ATAK then **tap** the Triple Dots button to open the overflow menu.
2. Scroll down to the bottom of the list then **tap** Settings.
3. **Tap** Tool Preferences under the “Manage My Device” section.



# Load CheckPoints™ Plugin for ATAK (Cont...)





4. **Tap** TAK Package Mgmt.
5. If the CheckPoints™ Plugin is not in the App/Plugin list **tap** the Refresh button then **tap** OK to Sync Packages.
6. **Tap** the Not Loaded checkbox.








# Load CheckPoints™ Plugin for ATAK (Cont...)




7. Review the CheckPoints™ Plugin details then ***tap Load.***
8. ***Tap OK*** to load the plugin.
9. ***CheckPoints*** is now loaded. Tap the back button on the EUD to return to the main ATAK Interface.



# Launch CheckPoints™ Plugin



1. **Tap** the Triple Dots button.
2. Scroll down to the bottom of the list and **tap** CheckPoints.
3. The first time CheckPoints is launched you will be provided a Camera Setup window where the camera names, IP address, and ports need to be entered. See the “Initial Camera Setup” section on page 6.



# Initial Camera Setup



1

Camera Setup

Camera 1 Name: Camera 1 Name

Camera 2 Name: Camera 2 Name

http:// url port1

port2

Cancel Confirm

2

Camera Setup

Camera 1 Name: Camera 1

Camera 2 Name: Camera 2

http:// 10.151.50.10 8011


8012

Cancel Confirm

1. **Enter** the Camera Names, URL, and Camera Ports.  
The Default Camera URL is: 10.151.50.10  
and the default ports are 8011 and 8012.
2. **Tap Confirm** to continue.
3. If your settings are correct you will see the video feeds in  
ATAK.



# CheckPoints™ Plugin for ATAK User Interface



**Camera 1**  
● Not Recording  
● No Motion  
View

**Camera 2**  
● Not Recording  
● No Motion  
View

View Camera 1  
("Active" camera highlighted in blue)

View Camera 2

**Tap View** under the camera name to change the active camera

**Memory Usage: 11%**  
Current memory utilization on the end user device (EUD)

**CheckPoints™ 01**  
Camera Label

**2020-04-28 14:31:39-06**  
Current Time Stamp

Take a Snapshot of the Current Camera View

Record the Current Camera View


Toggle the CheckPoints™ Camera/Field of View

**Close**  
Close the Plugin

**Files**  
View the Snapshots and Recordings



# CheckPoints™ Motion Detection



The Field of View on the map will turn from Green (Normal Status/No Motion) to Red (Alert Status / Motion Detected). Go to page 15 and 18 to place camera and field of view markers

**Camera 1**

- Recording
- Motion Detected

View





Camera 1 detects motion and begins to record if that feature has been turned on. Enabling this feature is discussed in the Preferences/Settings Section of the manual.



The CheckPoints™ System will draw a box around the area where motion is detected. The box will follow the “object” until it is out of view from the camera or until the system no longer detects motion.

# CheckPoints™ Camera Status Matrix



	No Motion Detected	Motion Detected
Inactive Camera	 <p>Camera 1 ● Not Recording ● No Motion View</p>	 <p>Camera 1 ● Recording ● Motion Detected View</p>
Active Camera	 <p>Camera 1 ● Not Recording ● No Motion View</p>	 <p>Camera 1 ● Recording ● Motion Detected View</p>

*Camera 1 Status Example*

**Inactive Camera** – The camera not currently displaying its video stream

**Active Camera** – The camera (highlighted in blue) currently displaying its video stream

**No Motion Detected** – Motion has not been detected by the CheckPoints™ system

**Motion Detected** – Motion has been detected by the CheckPoints™ System








# CheckPoints™ Plugin for ATAK: Files




# CheckPoints™ Plugin for ATAK: Files Overview



The CheckPoints Files allows users to view snapshots and recordings. These files are either manually created using the snapshot or record buttons   from the main interface or by toggling the CheckPoints™ settings to automatically record when motion is detected. Files tagged with A\_ were automatically captured and files with M\_ were manually captured.

Camera 1 Recordings	Camera 1 Snap Shots	
Camera 2 Recordings	Camera 2 Snapshots	
 A-Camera 1-2020-04-29 16_22_55_891.mp4	601.3 KB 00h:00m:07s	
 A-Camera 1-2020-04-29 16_23_11_753.mp4	4.3 MB 00h:00m:39s	
 A-Camera 1-2020-04-29 16_24_39_972.mp4	767.0 KB 00h:00m:09s	
 A-Camera 1-2020-04-29 16_24_55_139.mp4	5.0 MB 00h:00m:47s	
 A-Camera 1-2020-04-29 16_26_08_286.mp4	492.5 KB 00h:00m:06s	
 M-Camera 1-2020-04-29 16_21_55_773.mp4	30.8 KB 00h:00m:00s	
 M-Camera 1-2020-04-29 16_22_03_304.mp4	24.7 KB 00h:00m:00s	
<b>Delete</b>	<b>Rename</b>	<b>Play</b>
<b>Back</b>		



# CheckPoints™ Plugin for ATAK: Files - Recordings



Camera 1 Recordings	Camera 1 Snap Shots	
Camera 2 Recordings	Camera 2 Snapshots	
A-Camera 1-2020-04-29 16_22_55_891.mp4 601.3 KB 00h:00m:07s		
A-Camera 1-2020-04-29 16_23_11_753.mp4 4.3 MB 00h:00m:39s		
A-Camera 1-2020-04-29 16_24_39_972.mp4 767.0 KB 00h:00m:09s		
A-Camera 1-2020-04-29 16_24_55_139.mp4 5.0 MB 00h:00m:47s		
A-Camera 1-2020-04-29 16_26_08_286.mp4 492.5 KB 00h:00m:06s		
M-Camera 1-2020-04-29 16_21_55_773.mp4 30.8 KB 00h:00m:00s		
M-Camera 1-2020-04-29 16_22_03_304.mp4 24.7 KB 00h:00m:00s		
<b>Delete</b>	<b>Rename</b>	<b>Play</b>
<b>Back</b>		

Selected Camera

**Camera 1 Recordings**

**Camera 2 Recordings**

Selected Video File

A-Camera 1-2020-04-29 16\_24\_55\_139.mp4

A-Camera 1-2020-04-29 16\_26\_08\_286.mp4

**Delete** **Rename**

Delete Selected Video Rename Selected Video

**Play** **Back**

Play Selected Video Go Back to Files

# CheckPoints™ Plugin for ATAK: Files – Recordings (Cont...)



A-Camera 1-2020-04-29 16\_24\_55\_139.mp4  
19 of 23

CheckPoints 01  
2020-04-29 16:25:14-14

Video Recording File Syntax

A	Camera 2	2020-04-29-16_24_55_139	MP4
M	Camera 2	2020-04-29-11_53_11_526	MP4

1 2 3 4

1. A - Automatic Recording / M – Manual Recording
2. Camera Name
3. Date Time Stamp
4. File Extension

19 of 23

Current file of total files

Video Progress Bar

Previous Next








Go to Previous Video Go to Next Video

Play / Stop Video Back

Play / Stop Video Go Back to Files

# CheckPoints™ Plugin for ATAK: Files - Snapshots




Camera 1 Recordings	Camera 1 Snap Shots	
Camera 2 Recordings	Camera 2 Snapshots	
	A-Camera 2-2020-04-29 16_20_54_624.jpg 13.9 KB	
	A-Camera 2-2020-04-29 16_21_49_769.jpg 13.6 KB	
	A-Camera 2-2020-04-29 16_22_53_025.jpg 13.4 KB	
	A-Camera 2-2020-04-29 16_23_55_285.jpg 13.7 KB	
	A-Camera 2-2020-04-29 16_24_36_174.jpg 13.2 KB	
	A-Camera 2-2020-04-29 16_26_01_954.jpg 13.2 KB	
	M-Camera 2-2020-04-29 14_05_05_588.jpg 14.8 KB	
<b>Delete</b>	<b>Rename</b>	<b>View</b>
<b>Back</b>		


Selected Camera

**Camera 1 Snap Shots**

**Camera 2 Snapshots**

Selected File

 A-Camera 2-2020-04-29 16\_23\_55\_285.jpg

 A-Camera 2-2020-04-29 16\_24\_36\_174.jpg

**Delete** **Rename**

Delete Selected Video Rename Selected Video

**Play** **Back**

Play Selected Video Go Back to Files



# CheckPoints™ Plugin for ATAK: Files – Snapshots (Cont...)



Video Recording File Syntax

A	Camera 1	2020-04-29-16_14_541	JPG
M	Camera 1	2020-04-37-11_56_234	JPG

1      2                      3                      4

1. A - Automatic Snapshot / M – Manual Snapshot
2. Camera Name
3. Date Time Stamp
4. File Extension

8 of 20

Current file of total files

**Previous**                      **Next**

Go to Previous Snapshot                      Go to Next Snapshot


**Back**

Go Back to Files



# CheckPoints™ Plugin for ATAK: Place Camera

# CheckPoints™ Plugin for ATAK: Place Camera



1. **Tap** the Toggle Camera/FOV Button. (Gear Icon)
2. Select Camera 1 or Camera 2. This example will demonstrate placing camera 1. **Tap** Place Camera 1.
3. **Tap** the location of Camera 1 on the Map.


A Field of View (FOV) cone will automatically be placed at the camera location. Instructions on how to modify The FOV cone can be found on page 16.

*Repeat this process for Camera 2*






# CheckPoints™ Plugin for ATAK: Place Camera cont.



1. After placing your cameras location several settings will appear.
2. Adjust the Field of View parameters as needed.
  - Sensor Range, Bearing, and Field of View Angle can be set manually or with the slider bar.
  - The color of the Normal Status / No motion color can be changed as well as the FOV opacity.
  - After you are satisfied with your placement/settings **Tap** the Commit Cam 1,2 button.

# CheckPoints™ Plugin for ATAK: Radial Menu



Play Video  
(in ATAK Native Video Player)

Measure Distance from Camera  
to another POI on the map

Hide Field of View

**All other buttons are  
managed by the board**

**Tap** the Camera Icon on the map to open the Camera Options Radial Menu

\*Currently managed by the board and not the ATAK



# Dual Camera and FOV Example



# CheckPoints™ Plugin for ATAK: Dual Camera / FOV Example



In this example BOTH cameras are currently not detecting any motion and BOTH the FOVs are green



In this example only camera 2 is currently detecting motion and Camera 1 is not. Camera 2's FOV is red and Camera 1's is green.



# CheckPoints™ Plugin for ATAK: Preferences


# CheckPoints™ Plugin for ATAK: Preferences Overview



The CheckPoints™ Preferences allows the user to:





- Modify Camera Names
- Change IP Addresses and Ports
- Toggle Motion Alert Settings
- Modify Snapshot Settings
- Adjust the Orientation of the CheckPoints™ App
- Configure the Settings on the CheckPoints™ board  
(ADVANCED)\*

\*This should be done with extreme caution!







# CheckPoints™ Plugin for ATAK: Access Preferences



1. **Tap** the Triple Dots button.
2. **Tap** Settings.
3. **Tap** Tool Preferences.
4. **Tap** CheckPoints™ Preferences.




# CheckPoints™ Plugin for ATAK: Preferences – Stream Settings





1. Locate and **tap** Stream Settings under General Plugin Settings.
2. Change the Camera Setup parameters as needed. **Tap** Confirm to save the new settings. Continue to make changes to the preferences or **tap Back** on the EUD three (3) times to return to the main ATAK screen.

# CheckPoints™ Plugin for ATAK: Preferences – UDP Group and Port





1. Locate the and tap UDP Group and Port under General Settings.
2. Enter the desired Multicast and Port number then **tap Confirm**. (\*In most cases you shouldn't edit this!) Continue to make changes to the preferences or **tap back** on the EUD three (3) times to return to the main ATAK screen.



1. Locate the highlighted Motion Alert Settings.
2. **Toggle** the highlighted Camera Motion Alert Settings from Off to On as desired (Auto Record Video, Auto Snap Shot, Audio Alert, Vibration Alert). Settings for “Camera 1” and “Camera 2” are independent of each other. Changes must be made for both cameras. Continue to make changes to the preferences or **tap back** on the EUD three (3) times to return to the main ATAK screen.



The CheckPoints™ App provides visual, haptic, and audio alerts to users when the system detects motion.

# CheckPoints™ Plugin for ATAK: Preferences – Audio Alert Sound File





1. Locate and **tap** Audio Alert Sound File under Motion Alert Settings.
2. **Tap** the desired Audio Alert File then **tap** Confirm. Settings for “Camera 1” and “Camera 2” are independent of each other. Changes must be made for both cameras. Continue to make changes to the preferences or **tap** back on the EUD three (3) times to return to the main ATAK screen.

# CheckPoints™ Plugin for ATAK: Preferences – Snap Shot File Type



1. Locate and **tap** Snap Shot File Type under Other Settings.
2. **Tap** JPG or PNG to change the snapshot file type. The default value is JPG. Continue to make changes to the preferences or **tap** back on the EUD three (3) times to return to the main ATAK screen.



# CheckPoints™ Plugin for ATAK: Preferences – JPG Compression



1. Locate and **tap** Snap Shot JPG Compression Amount Type under Other Settings.
2. Enter the new compression value. The default value is 25%. Continue to make changes to the preferences or **tap** back on the EUD three (3) times to return to the main ATAK screen.






# CheckPoints™ Plugin for ATAK: Preferences – About



1. Locate and **tap** About CheckPoints™ Type under Other Settings.
2. **Tap** Close to exit the About window. Continue to make changes to the preferences or **tap** back on the EUD three (3) times to return to the main ATAK screen.



# CheckPoints™ Plugin for ATAK: Settings – Board Configuration



1. Locate and **tap** Configure CheckPoints™ Board under CheckPoints™ Board Configuration Settings
2. Read the warning message then **Tap** both Locked Buttons to set them to Confirm then tap Continue enter the Configuration Menu.  
\*WARNING\* Entering in invalid settings could potentially render the system inoperable.



# CheckPoints™ Board Configuration

# CheckPoints™ Board Configuration - Overview



Please see “CheckPoints™ Settings – Board Configuration” on Page xxx and follow the steps to access the Board Configuration Menu. Configuring the preferences options in this section assumes the user has done this step.


The CheckPoints™ Board Configuration allows the user to:

- Set Camera Label
- Adjust Camera Framerate
- Toggle Motion Detection, Threshold, and Noise Level
- Change Motion Marker
- Modify IP Addresses and Ports



*Remember – Cameras configurations are independent of each other. Changes must be done to BOTH cameras*

**\*\*IMPORTANT\*\*** After the configurations have been altered the board must be rebooted. This can be done by **tapping** the **Reboot CheckPoints™ Button**. Close the CheckPoints™ App and relaunch once the EUD receives a DHCP IP Address from the CheckPoints™ Board.

**Proceed with caution**




# CheckPoints™ Board Configuration – Connect to Board



1. Enter the IP Address of the board. The Default IP Address is 10.151.50.10.
  2. **Tap Connect.**
- Connection Status:**
- Not Connected** – The CheckPoints™ App is not logged into the Board

**Connecting...** – The CheckPoints™ App is trying to establish a logon session

**Connected** – The CheckPoints™ App is currently logged into the board.







# CheckPoints™ Board Configuration

## CheckPoints™ Configuration Settings

# CheckPoints™ Board Configuration – Configurations



1. Locate and **tap** Configuration under Configuration Settings.
2. Enter the new Camera Configurations such as Sensor Name, Cam Name, Port, and SA Publish Option then **tap** Commit.

You may continue to make changes to the board. When finished **Tap** the Reboot CheckPoints button.







# CheckPoints™ Board Configuration

## Camera Configuration Settings

# CheckPoints™ Board Configuration – Camera Configuration



1. Locate and **tap** Camera 1 or 2 under Camera Configuration Settings.
2. Enter the new Camera Settings then **tap** Commit.
  - i. If you are sending video over a tactical network use lower values (2-10) for the framerate and Quality ( less than 60)
  - ii. If you want to ignore small motion changes increase the Threshold to a higher value.
  - iii. If you want to ignore "electrostatic" effects (grey/black splotches) during low light environments increase the noise level.


You may continue to make changes to the board. When finished **Tap** the Reboot CheckPoints button.



# CheckPoints™ Board Configuration

## Motion Alert Settings

# CheckPoints™ Board Configuration – Motion Alerts\*\*



1. Locate and **tap** Motion Alerts under Motion Alert Settings.
2. Enter the new UDP Group, UDP Alert Port, and TCP Alert Port values (if needed) then **tap** Commit. \*\*Note: Most users DO NOT NEED to change these values!



You may continue to make changes to the board. When finished **Tap** the Reboot CheckPoints button.



# CheckPoints™ Board Configuration

## CheckPoints™ SA Network Settings

# CheckPoints™ Board Configuration – SA Network Settings



1. Locate and **tap** SA Network under SA Network Settings.
2. Enter the new Network Settings for the CheckPoints board then **tap** Commit.

You may continue to make changes to the board. When finished **Tap** the Reboot CheckPoints button.







# CheckPoints™ Board Configuration

## CheckPoints™ Network Settings

# CheckPoints™ Board Configuration – Network IP Address\*\*\*



1. Locate and **tap** Network under Network Settings.
2. Enter the new Network Settings for the CheckPoints board then **tap** Commit. \*\*\*Note: Please write down the new IP address before rebooting the system.

\*If your network setup requires a gateway, please **tap** Unicast or Both under Network Protocol. This will unhide the gateway option.

Gateway: 10.151.50.1



You may continue to make changes to the board. When finished **Tap** the Reboot CheckPoints button.




# CheckPoints™ Board Configuration

## Misc Settings



# CheckPoints™ Board Configuration – TCP Addresses



1. Locate and **tap** TCP Addresses at the bottom of the list.
2. Locate and **tap** the Add button.
3. Enter TCP Address then **tap** Confirm.





# CheckPoints™ Board Configuration – TCP Addresses cont.



1. When ready locate and ***tap*** Commit .
2. ***Tap*** Confirm Commit when ready.

# CheckPoints™ Board Configuration – Factory Defaults



1. Locate and **tap** Factory Defaults at the bottom of the list.
2. Remember the Default IP address and that Authoritative DHCP will be enabled if you proceed
3. You must reboot the board after selecting confirm.



